

## Programming DSS Buttons on the IPKII Phone

(Direct Station Selection)

1. Press the “**Speaker**” button.
2. Dial “**751**”, display shows “**Key Program**”.
3. Press the “**Button**” to program, display will show the current button number or Not Defined.
4. Dial “**01**”, display will show “**DSS/One Touch**”.
5. Dial the three digit “**Extension Number**” you want the button to call.
6. Press the “**Hold**” button to save.
7. You will hear confirmation “**Beeps**” if accepted.
8. To program another button start with step #3.
9. When finished press the “**Speaker**” button to disconnect.