

**Protégé CTX, MTX, LTX, System Date, and Time change instructions.**

1. Enter attendant programming mode.
2. Press the "function" key then dial "#" and "0".
3. Enter "1" for the tenant group.
4. Enter "000000" for the password. (or System Administrator's Password)
5. Press "F2" below the word show in the display
6. Press "F2" below the word next in the display.
7. Repeatedly press "F2" until "System Time" is displayed.
8. When "System Time" is displayed press "F3" below the word "Show" in the display.
9. The Year, Month, Day, Weekday, Hour and Minute settings Are displayed in turn.
10. Press "F2" for next until you wish to change the displayed Setting. Then presses "F3" below the word "chg" in the display.
11. Use the dial pad to enter the appropriate two-digit numbers For the Year, Day, Hour and Minute.
12. Months and weekdays can be scrolled by pressing the "F3" key.
13. Press "F2" when you have made your selection to advance to the next category.
14. Or press "Hold" to exit the programming mode at any point.

**Certified  
Alarm  
Co.**

*of Ala Inc*

**(256)383-1225**

**ABES-066  
TN C0550**