

**Accessing the Protege Voice, System Administrator's MailBox**

1. Press the Voice Mail Key, then at the Greeting Dial "\*" and "#".  
Or Dial the ProtegeVoice Access Code "730", then at the Greeting dial "#".
2. Dial the System Administrators Mail Box "555".
3. Enter the Password "0000". (or System Administrator's Password)
4. The Main menu now plays.

**Setting the Protege Voice Clock. (Date and Time)**

1. From the Main menu dial "5".
2. Enter the Date as a Six digit number (mmddyy), May 05,2001 is 050501  
The Date is played for confirmation.
3. Dial "\*" to return to the Mail meun or Continue.
4. Enter the Time in Six digit military time (hhmmss) 093000 AM is 0930, 0930 PM is 213000.  
The Time is played for confirmation.
5. Dial "\*" to exit the System.

**Certified  
Alarm  
Co.**

*of Ala Inc*

**(256)383-1225**

**ABES-066  
TN C0550**